



IT'S ALL IN THE DETAILS.

615.822.4392

# Heat Lamp

## Operating Instructions & Trouble Shooting Guideline

*\*This unit is designed to be used on a single dedicated 20amp circuit.*

Nemco 6000A-2

### Operating Instructions

1. Plug cord into grounded electrical outlet of the correct voltage (110). Electrical shock can occur if appliance is not grounded.
2. Place food products in a pan, located directly under the bulbs for best results.
3. Turn unit off when not in use.
4. To disconnect appliance, turn switch off and remove plug from power source.

### Operating Tips

1. Warning! All power must be disconnected at power source before any service procedure is performed.
2. This appliance is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Keep combustible materials, such as drapes and other furnishings, away from appliance.
3. Extreme caution is necessary when any appliance is used by or near children and whenever the appliance is left unattended.
4. Always unplug appliance when not in use and before cleaning, adjusting or maintaining this machine. To disconnect appliance, turn switch off and remove plug from power source.
5. Do not operate any appliance with a damaged cord or plug, after the appliance malfunctions, has been dropped, or damaged.
6. This appliance is not intended for wet or moist locations. Never locate appliance where it may fall into water.
7. Connect to properly grounded outlets only. Avoid the use of extension cords. Do not run cord under carpeting, runners, or the like. Arrange cord away from traffic area and where it will not create a trip hazard.
8. This appliance is equipped with a power cord with a three blade plug. Plug ONLY into a matching three blade outlet. DO NOT cut or break off the third blade or attempt to use with a two blade extension cord.
9. To prevent a possible fire, it is recommended that the unit is placed on a non-combustible surface.
10. This appliance has electrical parts. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.

### Troubleshooting Guidelines

#### LIGHTS NOT ON

- \*Check if unit is plugged in and power switch is turned to "ON" position.
- \*Check power at receptacle.
- \*Check if bulb has blown.

#### LOOSE SOCKETS

- \*Turn off power and check if socket is loose or broken. Remove light bulb and tighten socket screws as necessary.

## LOOSE HOODS

\*Turn off power and check if hood is loose. Remove light bulb and tighten hood screws as necessary.

## UNIT BLOWS FUSE OR CIRCUIT BREAKER

\*Check to make sure circuit is not overloaded.